

! New to !

STAINED GLASS LEADING?



These **5** essential tools will help you build your first leaded stained glass panel.

Lead Knife



Horseshoe Nails



Tallow Flux



Brass Wire Brush



Fid / Lathekin



Fid/Lathekin

**The multi-purpose
leadworker's tool!**

- **Open Lead Channels**
- **Shape Lead Came**
- **Burnish Copper**



Horse Shoe Nails

**Holds your panel securely
as you go along**

Tallow Flux

**A natural flux for use on lead came in
leaded window work.**

**Simply rub a little tallow onto your
lead joints prior to soldering to help
it flow and stick.**





Brass Wire Brush

Cleans lead joints before soldering

Lead Knife

The tool we recommend for all stained glass workers. Easy to use, long lasting and multi purpose.



Get All 5 Essential Tools Together As A Bundle & Save!



Protool Lead Knife

+



Horse Shoe Nails

+



Tallow Flux

+



Small Brass Wire Bristle Brush

+



Fid / All Nova Tool / Lathekin

