





## How to transport frit to the kiln using layering mix

Here's how to get added frit from one place to another for firing or just somewhere else to work on the piece.

This works with any brand or color of frit. Just mix it with our Layering Mix, place it where you want it to stay, let it dry and move it (upside down if you want) to where it needs to go.

Layering Mix looks milky in the bottle and cloudy when dried. It is very handy to keep frit in place. After it dries you can add more Layering Mix over the top of the dried frit to make it even more stable. Let it dry for 24 hours before transporting.



Dried, poured enamels with frit mixed with UGC Layering Mix for the center.



Close up



Fired on top of a dried poured enamel piece. Clear frit.